
ILLUSTRATED PARTS





1996


Hydrostatic Lawn Tractors 690-699 Series



PARTS LIST FOR MODEL 690 LAWN TRACTOR

ìEF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	. DESCRIPTION
1	783-0250		Hood	26	725-0634		Light Switch**
2	738-0952		Shld. Bolt .375" Dia. x .125" Lg.	27	725-0925		Ammeter**
4	710-0258		Hex Bolt 1/4-20 x .62" Lg.*	32	710-0286		Truss Mach. Scr. 1/4-20 x .5" Lg.
6	712-0271		Hex Sems Nut 1/4-20 Thd.	35	17871B	N	Fender w/Cutout
7	749-0812		Grille Support Rod	38	710-0726		Hex Wash. Hd. AB-Tap Scr.
8	731-1099A		Headlight Lens				5/16 x .75" Lg.
9	712-3027_		Flange L-Nut 1/4-20 Thd.	41	831-0823A		Throttle Box Ass'y.
10	731-1097D	N	Grille	42	710-0779A		Truss Mach. AB-Ťap Scr.
13	725-0963		Lamp				#10 x .5" Lg.
14	725-1649		Socket _	43	746-0776		Throttle Control Wire†
15	710-0703		Carriage Bolt 1/4-20 x .75" Lg.		746-0634		Throttle Control Wire††
16	710-0599		Hex Wash. Hd. TT-Tap Scr.		746-0638		Throttle Control Wire (Tec.)
			1/4-20 x .5" Lg.	44	777-9206		Grille Reflector Label
17	736-0173		Fl-Wash281" I.D. x .73" O.D.	45	710-0603		Hex Wash. Hd. B-Tap Scr.
18	726-0233		Bolt Retainer 1/4" I.D.				5/16-18 x .5" Lg.
19	712-0185		Speed Nut 1/4-20 Thd.	46	17782		Choke Retainer
20	710-0118		Hex Bolt 5/16-18 x .75" Lg.	47	710-0642		Hex TT-Tap Scr. 1/4-20 x .75" Lg.
21	17632A		Gas Tank Support Brkt.	48	726-0211		U-Nut 5/16-18 Thd.
22	731-1096B		Dash w/Ammeter Hole		629-0308		Headlight Harness (Not Shown)
	731-1337A		Dash w/o Ammeter Hole				
23	725-0267		Ignition Switch				
24	725-0201		Ignition Key				
25	746-0616A		Choke Control†		İ		
	746-0614A		Choke Control††				
	746-0720		Choke Control (Tec.)				
ļ	746-3021		Choke Control (Vanguard &				
			O.H.V.)				


^{**} Optional Parts † Used w/Single Cylinder Engine Only. †† Used w/Twin Cylinder Engine Only.



PARTS LIST FOR MODEL 693 LAWN TRACTOR

₹EF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
1	783-0250		Hood	26	725-0634		Light Switch**
2	738-0952		Shld. Bolt .375" Dia. x .125" Lg.	27	725-0925		Ammeter**
6	712-0271		Hex Sems Nut 1/4-20 Thd.	32	710-0286		Truss Mach. Scr. 1/4-20 x .5" Lg.
9	712-3027		Flange L-Nut 1/4-20 Thd.	35	17871B		Fender
10	783-0156A	N	Grille	38	710-0726		Hex Wash. Hd. AB-Tap Scr.
13	725-0963		Lamp				5/16 x .75" Lg.
14	725-1651		Socket	41	831-0823A		Throttle Box Ass'y.
15	710-0703		Carriage Bolt 1/4-20 x .75" Lg.	42	710-0779A		Truss Mach. AB-Tap Scr.
16	710-0599		Hex Wash. Hd. TT-Tap Scr.				#10 x .5" Lg.
			1/4-20 x .5" Lg.	43	746-0776		Throttle Control Wire†
17	736-0173		FI-Wash281" I.D. x .73" O.D.		746-0634		Throttle Control Wire††
18	726-0233		Bolt Retainer 1/4" I.D.		746-0638		Throttle Control Wire (Tec.)
19	712-0185		Speed Nut 1/4-20 Thd.	45	710-0603		Hex Wash. Hd. B-Tap Scr.
20	710-0118		Hex Bolt 5/16-18 x .75" Lg.				5/16-18 x .5" Lg.
21	17632A		Gas Tank Support Brkt.	46	17782		Choke Retainer
22	731-1096B		Dash w/Ammeter Hole	47	710-0642		Hex TT-Tap Scr. 1/4-20 x .75"
	731-1337A		Dash w/o Ammeter Hole				Lg.
23	725-0267		Ignition Switch	49	731-1503A	N	Lens
24	725-0201		Ignition Key	50	783-0151		Side Panel—L.H.
25	746-0616A		Choke Control†	51	783-0150A		Side Panel—R.H.
	746-0614A		Choke Control††	71	726-0211		U-Nut 5/16-18 Thd.
	746-3021		Choke Control (Vanguard & O.H.V.)		629-0309		Headlight Harness (Not Shown)
	746-0720		Choke Control (Tec.)				


^{**} Optional Parts
† Used w/Single Cylinder Engine Only.
†† Used w/Twin Cylinder Engine Only.



PARTS LIST FOR MODEL 694 LAWN TRACTOR

REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
13	712-0271		Hex Sems Nut 1/4-20 Thd.	80	710-0642		Hex Wash. Hd. Tap Scr.
26	710-0726		Hex Wash. Hd. AB-Tap Scr.				1/4 x .75" Lg.
			5/16 x .75" Lg.	81	710-0599		Hex Tap Scr. 1/4-20 x .5" Lg.
27	736-0142		FI-Wash218" Ĭ.D. x .5" O.D.	82	726-0233		Push Nut Fastener
32	731-0911		Rubber Foot Pad—L.H.	83	736-0176		Fl-Wash27" I.D. x .948"
			(Optional)	84	725-0925		Ammeter
	731-0912		Rubber Foot Pad—R.H.	85	712-0185		Speed Nut 1/4-20 Thd.
			(Optional)	86	731-0961A		Dash Panel
33	710-0118		Hex Bolt 5/16-18 x .75" Lg.*	87	710-1005		Hex Wash. Hd. B-Tap Scr.
38	710-0258		Hex Bolt 1/4-20 x .62" Lg.*				1/4 x .75" Lg.
51	712-0265		Hex Sems Nut 5/16-18 Thd.	88	783-0121		Hood Reinforcement
65	783-0041A		Pivot Bar Brkt.	89	783-0123		Hood Hinge
66	783-0350		Fender	90	17762		Hood Reinforcement Spacer
67	710-0167		Carriage Bolt 1/4-20 x .62" Lg.	92	17223		Light Bracket
68	725-3000		Reflector (Optional)	93	712-0158		Hex L-Nut 5/16-18 Thd.
69 70	726-0211		U-Nut 5/16-18 Thd.	94	712-0107		Hex L-Nut 1/4-20 Thd.
70	746-0776 746-0634		Throttle Wire 18.5" Lg.†	95	712-3007		Hex Jam Nut 5/16-18 Thd.
	746-0636		Throttle Wire 35" Lg.††	96 97	710-3038		Hex Bolt 5/16-18 x 7/8" Lg.
	740-0030		Throttle Wire 28" Lg. (Kohler Engine)	97	710-0351		Truss Mach. B-Tap Scr. #10 x .5" Lg.
71	831-0823A		Throttle Control Box Ass'y.	98	731-1434		Side Cover—R.H.
72	725-1341B		Ignition Key		731-1435		Side Cover—L.H. (Not Shown)
73	725-1346		Ignition Switch Nut	99	731-1442A		Grille
74	725-1347		Ignition Switch Cap	100	731-0949		Lens—L.H.
75	725-1396		Ignition Switch		731-0948		Lens—R.H.
76	731-1433		Hood	101	725-1650		Twist Lock—Lamp Socket
77	710-0779A		Truss Mach. AB-Tap Scr. #10 x	102	725-0963		Lamp
			.5" Lg.	103	731-0705		Headlight Housing
78	725-0634		Light Switch	104	17300D		Dash Support Brkt.
79	746-3021		Choke Control (Single Cylinder	105	17633A		Support Brkt.
		Î	and Kohler Engine)	106	17782		Choke Retainer
	746-0614A		Choke Control††				


†Used with Single Cylinder Engine Only. ††Used with Twin Cylinder Engine Only.



PARTS LIST FOR MODEL 695 LAWN TRACTOR

REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
1	783-0250		Hood	26	725-0634		Light Switch**
2	738-0952		Shld. Bolt .375" Dia. x .125" Lg.	27	725-0925		Ammeter**
6	712-0271		Hex Sems Nut 1/4-20 Thd.	32	710-0286		Truss Mach. Scr. 1/4-20 x .5" Lg.
8	731-1099A		Headlight Lens	35	17871B	Ν	Fender w/Cutout
9	712-3027		Flange L-Nut 1/4-20 Thd.	38	710-0726		Hex Wash. Hd. AB-Tap Scr.
10	731-1097D	N	Grille				5/16 x .75" Lg.
11	736-3078		FI-Wash344" I.D. x 1" O.D.	41	831-0823A		Throttle Box Ass'y.
12	712-0267		Hex Nut 5/16-18 Thd.*	42	710-0779A		Truss Mach. AB-Tap Scr.
13	725-0963		Lamp				#10 x .5" Lg.
14	725-1649		Socket	43	746-0776		Throttle Control Wire†
15	710-0703		Carriage Bolt 1/4-20 x .75" Lg.		746-0634		Throttle Control Wire††
16	710-0599		Hex Wash. Hd. TT-Tap Scr.		746-0638		Throttle Control Wire (Tec.)
4-	700 0470		1/4-20 x .5" Lg.	44	777-9206		Grille Reflector Label
17	736-0173		Fl-Wash281" I.D. x .73" O.D.	45	710-0603		Hex Wash. Hd. B-Tap Scr.
18	726-0233		Bolt Retainer 1/4" I.D.		47700		5/16-18 x .5" Lg.
19	712-0185		Speed Nut 1/4-20 Thd.	46	17782		Choke Retainer
20	710-0118		Hex Bolt 5/16-18 x .75" Lg.	47	710-0642		Hex TT-Tap Scr. 1/4-20 x .75"
21 22	17632A		Gas Tank Support Brkt.	40	700 01504		Lg.
22	731-1096B		Dash w/Ammeter Hole	49	783-0150A		Side Panel—R.H.
22	731-1337A 725-0267		Dash w/o Ammeter Hole	50	783-0151		Side Panel—L.H.
23 24	725-0201		Ignition Switch	71	726-0211		U-Nut 5/16-18 Thd.
2 4 25	746-0616A		Ignition Key Choke Control†		629-0308		Headlight Harness (Not Shown)
25	746-0616A		Choke Control††				
	746-3021		Choke Control (Vanguard &				
	170-5021		O.H.V.)				
	746-0720		Choke Control (Tec.)				


^{**} Optional Parts
† Used w/Single Cylinder Engine Only.
†† Used w/Twin Cylinder Engine Only.



PARTS LIST FOR MODEL 699 LAWN TRACTOR

REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
3	710-0118		Hex Bolt 5/16-18 x .75" Lg.	36	710-0599		Hex Wash. Hd. B-Tap Scr.
5	710-0603		Hex Wash. Hd. Scr. 5/16"x .5"				1/4-20 x .5" Lg.
			Lg.	37	750-0218		Spacer .262" Ĭ.D. x .31"
7	710-0167		Carriage Bolt 1/4-20 x .5" Lg.	39	16903A		Hood Plate
8	710-0726		Hex Wash. Hd. Tap Scr. 5/16 x .75" Lg.	40	710-1005		Hex Wash. Hd. Tap Scr. 1/4-20 x .5" Lg.
9	17633A		Support Bracket	41	731-1048B		Dash
10	17300D		Dash Support Bracket	42	725-0925		Ammeter
11	783-0350		Rear Fender	43	831-0823A		Throttle Control Box Ass'y.
12	730-3000		Reflector (Optional)	44	710-0919		Mach. Scr. #10 x .44" Lg.
14	17308A		Side Panel—R.H.†	45	746-0616A		Choke Control 23" Lg.†
	17309A		Side Panel—L.H. (Not Shown)†		746-0614A		Choke Control 38" Lg.††
	16723		Side Panel—R.H. (16 H.P. Tec.)		746-3021		Choke Control (Vanguard &
	17458A		Side Panel w/Foam—R.H.††				O.H.V.)
	17459A		Side Panel Ass'y. w/Foam—L.H.		746-0720		Choke Control (Tec.)
			(Not Shown)††	46	746-0776		Throttle Control Wire 18.5" Lg.†
15	710-0286		Truss Mach. Scr. 1/4-20 x .5" Lg.		746-0634		Throttle Control Wire 35" Lg.††
16	710-0166		Truss Mach. Scr. 1/4-20 x 1.0" Lg.		746-0638		Throttle Control Wire 22" Lg. (Tec.)
17	710-1026		Hex Wash. TT-Tap Scr. 1/4-20 x 1.75" Lg.	47 48	725-0267 725-0201		Ignition Switch Ignition Key
18	750-0768		Spacer .26" I.D. x 1.32"	49	731-1491		Hood—Red
19	710-0642		Hex Rolling Tap Scr. 1/4-20 x	_	731-1492		HoodMidnight Blue
			.75" Lg.		731-1497		Hood—Oyster Gray
21	731-0511-1	8	Trim Strip—18" Lg.		731-1531		Hood—Charcoal Gray
22	736-0329	I	L-Wash. 1/4" I.D.*		731-1532		Hood-Orange
23	712-0271		Hex Sems Nut 1/4-20 Thd.	71	749-0814		Grille Support Tube
24	726-0201		Speed Nut 5/16" Thd.	73	736-0607		External L-Wash. 5/16" I.D.
27	17410		Grille Ass'y.	76	17782		Choke Retainer
28	731-1044		Headlight Lens	77	725-0634		Light Switch
29	731-0705		Headlamp Housing	78	736-3010		FI-Wash406" I.D. x .812" O.D.
30	725-0963		Headlamp	79	710-0206		Hex Bolt 1/4-20 x .88" Lg.
31	725-1650		Twist Lock Lamp Socket	80	783-0013		Dash Fastening Tab
32	736-0242		Bell-Wash345" I.D. x .88"	81	725-0157		Cable Tie
33	712-0429		Hex L-Nut 5/16-18 Thd.	82	777-8568A		Chrome Label
34	735-0126		Rubber Washer	83	726-0211		U-Nut 5/16-18 Thd.
35	783-0190		Hood Hinge				

[†]Used with Single Cylinder Engine Only. ††Used with Twin Cylinder Engine Only.




3E - Page 12

PARTS LIST FOR MODELS 690 THRU 699 LAWN TRACTORS

REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
1	731-0220		Steering Wheel Cap	31	712-0711		Hex Jam Nut 3/8-24 Thd.*
•	731-1459		Steering Wheel Cap (Sq.—MTD)	32	**		Front Axle Ass'y.—R.H.
	731-1460		Steering Wheel Cap (Square—	33	**		Wheel Ass'y. Comp.
			No Logo)	34	**		Front Wheel Rim Only
2	710-0643		Hex Bolt 5/16-18 x 1" Lg.	35	**		Bearing
3	736-0242		Belleville Wash345" I.D.	36	736-0285		FI-Wash635 I.D. x 1.59" O.D.
4	731-1693	N	Steering Wheel (3 Spoke)†	37	731-0484A		Front Wheel Hub Cap
	731-1687	Ν	Steering Wheel (3 Spoke)††		731-1787		Spoked Hub Cap (Yellow—Opt.)
	631-0027		Steering Wheel (4 Spoke)		734-1613		Spoked Hub Cap (Gray—Opt.)
5	731-0559		Steering Bellow—4.5" (Style 8)		734-1612		Spoked Hub Cap (Beige—Opt.)
	731-0954		Steering Bellow—9" (Style 0, 1,	38	714-0470		Cotter Pin 1/8" Dia. x 1.25"*
			3, 4, 5, 6, 9)	39	736-0531		Fl-Wash640" I.D. x 1.24" O.D.
	731-1542		Steering Bellow—3.25" (Style 7)	40	726-0214		Push Cap 5/8" Dia. Rod
7	741-0587		Flange Bearing .628" I.D. x	42	712-0262		Hex Jam Nut 3/8-24 Thd.
			1.36 O.D. (Štyle 8)	43	710-1309		Hex Patch Bolt 5/16-18 x .62"*
9	17198A		Retainer Plate	44	736-0119	,	L-Wash. 5/16" I.D.*
10	738-0141		Shoulder Bolt .437" Dia. x	45	736-0343		FI-Wash33" I.D. x 1.25" O.D.
			.35 Lg. 5/16-18 Thd.	46	748-0389		Cap
11	710-0152		Hex Bolt 3/8-24 x 1.0" Lg. (Gr. 5)	47	712-0214		Hex Cent. L-Nut 3/8-24 Thd.
13	750-0535		Spacer .380" I.D. x .625" O.D.	48	736-0169		L-Wash. 3/8" I.D.*
			x .227	49	712-0158		Hex Cent. L-Nut 5/16-18 Thd.
14	736-0217		L-Wash. 3/8" I.D. (H.D.)	50	736-0119		L-Wash. 5/16" I.D.*
15	710-0726		Hex Wash. Hd. Self-Tap Scr.	51	717-0622A		Steering Gear Segment
16	711-1068	N	Steering Drag Link	52	741-0656	N	Hex Flg. Brg634 I.D.
17	783-0041A	Ν	Front Pivot Brkt.	53	736-0187		FI-Wash. (Hardened)
18	738-0527		Shoulder Bolt .498" Dia. x 2.04	54	738-0919	N	Steering Shaft
			Lg. 3/8-16 Thd.	57	710-0837		Oval Hd. Cr.—Sunk Scr.
19	712-0431		Flanged L- Nut 3/8-16 Thd.*		700 0074		#10 x 5/8" Lg. (Style 8)
21	712-0411		Hex L-Nut 5/16-24 Thd.	58	736-0271		Wave-Wash32" I.D. x .62" O.D.
22	16481A		Steering Arm Front Axle	59	736-0187		FI-Wash. (Hardened)
23	710-0772		Hex Bolt 5/16-24 x 2.00" Lg. (Gr.5)	60	723-3018		Drag Link Ball Joint 3/8-24 Thd.
24	741-0659	Ŋ	Hex Flg. Brg632 I.D.	61	736-0607		Ext. L-Wash. 5/16" I.D.
25	683-0128	N	Pivot Bar Ass'y.	63	727-0425A		Spring Clip (Used w/Spoked
26			Front Axle Ass'y.—L.H.	0.4	700 0050		Hub Cap)
27	712-0241		Hex Nut 3/8-24 Thd.*	64	736-0356	K.	Bell-Wash39" I.D. x 1.38" O.D.
28	736-0169		L-Wash. 3/8" I.D.*	65	731-1291A	N	Pivot Bar End Cap (Optional)
29	723-3018		Ball Joint 3/8-24 Thd.	66	710-0459	K 1	Hex Bolt 3/8-24 x 1.5" Lg. (Gr. 5)
30	747-0753		Tie Rod (Adjustable)	69	731-1699	N	Axle Cap
	747-0861		Tie Rod (Non-Adjustable)	70	731-0955	L	Steering Wheel Insert (Optional)


**FRONT WHEEL CHART

Description	15" x 6" (Round Shoulder)	15" x 6" (Square Shoulder)
Wheel Ass'y. Comp.	634-0056	634-0105
Tire Only Rim Only	734-0864 634-0024	734-1731 634-0024
Bearing	741-0487A	741-0487A
Air Valve Grease Fitting (Optional)	734-0255 737-0211	734-0255 737-0211
Grease Plug	737-0212	737-0212
Front Axle Ass'y.—L.H. Front Axle Ass'y.—R.H.	683-0127 683-0126	683-0127 683-0126
Front Axle Ass'y.—L.H. (46" Deck) Front Axle Ass'y.—R.H. (46" Deck)	683-0124 683-0125	683-0124 683-0125



[†] Uses Round Steering Wheel Cap †† Uses Square Steering Wheel Cap

^{*}For faster service obtain standard nuts, bolts and washers locally. If these items cannot be obtained locally, order by part number and size as shown on parts list.




PARTS LIST FOR MODELS 690 THRU 699 LAWN TRACTORS

			PARTS LIST FOR MODELS 69			- 11170	
REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
1	732-0750A	N	Spring Switch	64	711-0832		Ferrule 3/8-24 Thd.
2	712-0265		Hex Sems Nut 5/16-18 Thd.	65	747-0365		Control Rod
4	731-1053B		Index Bracket	66	723-0351		Ball Joint 3/8-24 Thd.
5	710-0924		Pan Hd. Mach. Scr. 1/4-20 x	67	748-0234		Shld. Spacer .5" Dia. x .27" Lg.
			.75" Lg.	68	736-0159		FI-Wash349" I.D. x .879" O.D.
6	710-0599		Hex Wash. Hd. TT-Tap Scr.	69	710-3007		Hex Tap Scr. #12 x 3/8" Lg.
			1/4-20 x .5" Lg.	70	731-1449		Fan
7	712-0138		Hex Nut 1/4-28 Thd.	71	712-0333		Hex Nut 1/2-20 Thd.
8	736-0329		L-Wash. 1/4" I.D.*	72	736-0921		L-Wash. 1/2" I.D.*
10	710-0195		Hex. Bolt 1/4-28 x .62" Lg.	73	712-0241		Hex Nut 3/8-24 Thd.
11	783-0310	N	Lower Frame Ass'y.	74	736-0169		L-Wash. 3/8" I.D.
14	725-1426		Solenoid	75	756-0975		Transmission Pulley Wire Ring
15	736-0222		Ext. L-Wash. 1/4" I.D.	76 77	732-0729 754-0349		"V"-Belt
17	750-0956		Spacer	78	756-0981		FI-Idler Pulley 2.75" O.D.
18	756-0983		Engine Pulley Belt Guard Stud 4.75" Lg.	79	720-0238		Rod End Grip
19	711-1044		FI-Wash. 7/16" I.D. x 1.25" O.D.	80	747-0894		Bypass Control Lever
20 21	736-0322 736-0171		L-Wash. 7/16" I.D.*	81	783-0085		Transaxle Support BrktL.H.
22	710-0757		Hex Bolt 7/16-20 x 1.5" Lg.	82	710-0528		Hex Bolt 5/16-18 x 1.25" Lg.
23	735-0196		Foot Pad	83	732-0384		Ext. Spring 6.12
24	683-0049		Brake Lockout Brkt. Ass'y.	84	683-0051		Idler Brkt. Ass'y.
26	732-0728		Foot Pedal Return Spring	85	710-0116		Hex Bolt 5/16-18 x 2.5" Lg.*
27	738-0296		Shld. Bolt .437" Dia. x .268"	86	710-0118		Hex Bolt 5/16-18 x .75" Lg.*
28	736-0406		FI-Wash. 7/16" I.D. x 1-3/8" O.D.	87	748-0234		Shld. Spacer .5" Dia. x .27" Lg.
29	747-0608A	N	Lock-up Rod	88	783-0086A		Transaxle Support BrktR.H.
30	17755A	''	Bracket	89	747-0886		Brake Rod 24.94" Lg.
31	736-0119		L-Wash. 5/16" I.D.*	90	732-0716		Ext. Spring
32	712-0267		Hex Nut 5/16-18 Thd.*	91	747-0893		Bypass Actuator Rod
. 33	720-0166		Ball Knob	92	736-0142		Fl-Wash281" I.D. x .5" O.D.
34	732-0727		Neutral Return Spring	93	783-0098		Bypass Adjustment Brkt.
35	712-0273		Hex Nut 5/16-24 Thd.	94	736-0222		External L-Wash. 1/4" I.D.
36	736-3078		Fl-Wash344" I.D. x 1" O.D.	95	731-1086A		Sleeve .758" I.D. x 1" O.D.
37	783-0092		Scissor-Flat	96	710-0604	ł	Hex. TT-Tap Scr. 5/16-18 x .62"
38	736-0362		FI-Wash33" I.D. x 1.25" O.D.	97	17994		Retainer BrktTransaxle
39	750-0808		Spacer	98	710-0176 710-3195		Hex Bolt 5/16-18 x 2.75" Lg. Hex Bolt 5/16-18 x 4.5" Lg.
40	736-0219		Bell-Wash4" I.D. x 1.13" O.D.		/10-3195		(Used w/46" Deck)
41	761-0196		Friction Washer Centering Gauge Spacer	99	732-0250		Tension Spring
42	750-0918 783-0095		Neutral Return Mtg. Brkt.	100	710-0888		Hex Bolt 5/16-24 x 1" Lg.
43	736-0270		Bell-Wash265" I.D. x .75" O.D.	100	710-0000		(Special)
45	732-0718		Comp. Spring 1.19" Lg.	101	710-0224		Hex Wash. Hd. AB-Tap Scr.
46	736-3092		FI-Wash26" I.D. x .72" O.D.				#10 x .5" Lg.
47	712-0123		Hex Nut 5/16-24 Thd.	107	647-0008A		Speed Control Lever Ass'y.
48	710-0299	`	Hex Bolt 1/4-28 x 1" Lg. (Gr. 5)	108	17668		Axle Support BrktR.H.
49	710-1012		Rib Neck Bolt 5/16-24 x .84" Lg.	-	17669		Axle Support BrktL.H.
50	783-0093		Scissor-Offset				(Not Shown)
51	747-0887		Neutral Return Rod	109	732-0433		Ext. Spring 2.75" Lg.
52	738-0879		Friction Disc Stud	110	736-0141		Spr-Wash445" I.D. x .75" O.D.
53	748-0368		Shid. Spacer	111	17840		Transaxle Mtg. Brkt.
54	783-0096		Neutral Return Lever	112	725-1657A		Safety Switch (Clutch)
55	736-3092		FI-Wash265" I.D. x 1" O.D.	115	710-0650	١	Hex TT-Tap Scr. 5/16-18 x .75"
56	736-0329		L-Wash. 1/4" I.D.*	116	683-0123	N	Clutch/Brake Pedal Ass'y.
57	712-0287		Hex Nut 1/4-20 Thd.*	117	750-0802		Spacer .63" I.D.
58	714-0104		Hairpin Clip	118	17860		Pedal Bracket
59	736-0262		Fl-Wash375" I.D. x .87" O.D.	119	736-3008		FI-Wash344" I.D. x .75" O.D.
60	736-0413		Spring Wash39" I.D.	120 121	714-0111 714-0470		Cotter Pin 3/32" Dia. Cotter Pin 1/8" Dia.
61	712-0116		Hex L-Nut 3/8-24 Thd.	122	736-0140		FI-Wash385" I.D. x .62" O.D.
62	712-0711		Hex Jam Nut 3/8-24 Thd. Neutral Return Brkt.	123	710-0227		Hex AB-Tap Scr. #8 x .5" Lg.
63	783-0090A		INGULIAL DELUIH DIKL	123	110-0221	L	TICK AD TUP COL. HO X .O Lg.


PARTS LIST FOR MODELS 690 THRU 699 LAWN TRACTORS

REF. NO.	PART NO.	CODE	DESCRIPTION		REF. NO.	PART NO.	CODE	DESCRIPTION
124	726-0320		Insulator Nut Plate		139	710-0627		Hex Bolt 5/16-24 x .75" Lg.
125	725-1643		Reverse Safety Switch		140	736-0242		Bell-Wash345" I.D. x .88" O.D. '
126	725-1399		Extension Wire		141	734-0255		Air Valve
127	710-0520		Hex Bolt 3/8-16 x 1.5" L	g.	142	**		Rim Only
128	756-0116		Idler Pulley		143	**		Wheel Ass'y. Comp.
129	736-0280		Fl-Wash39" I.D.			**		Tire Only
130	712-0798		Hex Nut 3/8-16 Thd.*		144	734-1615		Hub Cap (Gray—Optional)
131	720-0218		Shift Knob			734-1614		Hub Cap (Beige—Optional)
133	731-1481		Vent Cap			734-1788		Hub Cap (Yellow—Optional)
134	731-1480		Plastic Vent		145	727-0425A		Spring Člip
135	726-0324		Clamp		146	783-0099		Idler Bracket
136	721-0330		"O"-Ring		147	710-1315		Hex TT-Tap Scr. 3/8-16 x 1.25"
137	731-1485		Hose Fitting		148	750-0258		Spacer .32" I.D. x .75" O.D.
138	751-0588-1	8	Fuel Line 18" Lg.					(Used w/46" Deck)

Models 690 thru 699



Models 096 (38") and 097 (42")




PARTS LIST FOR MODELS 690 THRU 699 LAWN TRACTORS

REF. NO.	PART NO.	QTY.	DESCRIPTION
1	718-0255A		Transmission Comp.
2	HG-9008000-0128	1	Seal-Lip
	HG-9008000-0126	1	Seal-Lip
4 5	HG-45074	1	Seal—Lip 10X25X7
5	HG-50126	1	Arm—Bypass
6	HG-44870	1	Ring—Retaining
7	HG-44094	1	Arm—Actuating
8	HG-44891	2	Pin-Actuating
9	HG-50108	1	Nut—Hex Lock 5/16-24 UNJC
10	HG-44130	1	Washer 7/16" x 7/8" x .06"
11	HG-50042	1	Breather Ass'y.
12	HG-45007	1	Arm—Control
13	HG-50034	1	Puck-Dampener
14	HG-50018	1	Set Screw
15	HG-50129	1	Strap, Locking

PARTS LIST FOR MODELS 096 AND 097 MULCHING KITS

	MOLETING KITS								
REF. NO.	PART NO.	DESCRIPTION	QTY.						
1	710-0134	Carriage Bolt 1/4-20 x .62" Lg.	2						
2	710-0597	Hex Bolt 1/4-20 x 1" Lg.	1						
3	710-3029	Hex Bolt 7/16-20 x 1.25" Lg.							
		(Gr. 5)	4						
4	710-0932	Carriage Bolt 1/4-20 x 1" Lg.	1						
5	711-0957	Retaining Bolt	1						
6 7	712-0378	Hex Nut 7/16-20 Thd.	4						
7	712-0287	Hex Nut 1/4-20 Thd.	3						
8	712-0291	Hex L-Nut 1/4-20 Thd.	1						
9	712-0397	Wing Nut	3 1 2 4 3 2 2 2 2 1						
10	736-0171	L-Wash. 7/16" I.D.	4						
	736-0329	L-Wash. 1/4" I.D.	3						
12	742-0539	Mulching Blade 12.5"	2						
13	742-0537	Mulching Blade 19.38" (096)	2						
	742-0538	Mulching Blade 21.2" (097)	2						
14	748-0365	Blade Adapter	2						
15	783-0024	Top Mulching Baffle (096)	1						
	783-0026	Top Mulching Baffle (097)	1						
16	783-0025	Side Mulching Baffle (096)	1						
	783-0027	Side Mulching Baffle (097)	1						
17	783-0028	Locking Bracket	1						
_	736-0217	L-Wash. 3/8" I.D.	2 2						
19	710-1039	Hex Bolt 3/8-24 x 1" Lg. (Gr. 8)	2						


3E - Page 16



PARTS LIST FOR MODELS 690 THRU 699 LAWN TRACTORS

REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
2	710-1208		Hex Wash. Hd. Tap Scr.	41	712-0798		Hex Nut 3/8-16 Thd.*
			5/16-18 x 3.25" Lg.	42	732-0581B		Extension Spring 5.31" Lg.
3	738-0155		Shld. Bolt .437" Dia. x .162"	44	725-1707	N	12-V Battery
4	738-0145		Shld. Bolt .50" Dia. x .84"	45	783-0043		Upper Frame—L.H.
5	736-0141		Spr-Wash445" I.D. x .75	46	783-0133A		Shift Cover
6	783-0039		Seat Pivot Bracket	48	726-0279		Insulator Plate
7	751-0603		Fuel Cap	49	17951		Seat Pivot Brkt. Support—L.H.
8	751-0553		Fuel Tank (12.5 H.P. & Smaller)	50	783-0355	N	Hitch Plate
	751-0555		Fuel Tank (13 H.P. & Larger)	51	712-0267		Hex Nut 5/16-18 Thd.*
9	726-0209		Tie Strap	52	736-0119		L-Wash. 5/16" I.D.*
10	751-0535-1	5	Fuel Line	53	17239A		Seat Lift Brkt.
11	726-0205		Hose Clamp	54	757-0363		Seat 8-7/8" High
13	712-0287		Hex Nut 1/4-20 Thd.*		757-0364		Seat 8-7/8" High (Yellow)
14	736-0329		L-Wash. 1/4" I.D.		757-0360		Seat 10-5/8" High
16	732-0735		Compression Spring		757-0365		Seat 10-5/8" High (Yellow)
21	738-0526		Running Board Rod		757-0350		Seat 14-1/4" High
22	710-0227		Hex Wash, Hd. AB-Tap Scr.		757-0372		Seat 14-1/4" High (Yellow)
			#8 x .50" Lg	55	17950		Seat Pivot Brkt. Support—R.H.
23	726-0139		Speed Nut #10Z	56	738-0296		Shld. Bolt .437" Dia. x .268"
24	783-0041		Front Pivot Brkt.	57	725-1303		Spring Switch (Seat—Outer)
25	710-0870		Hex Tap Scr. 3/8-16 x .62" Lg.	59	710-0650		Hex Wash. TT-Tap Scr. 5/16-18
26	710-0726		Hex Wash. Hd. AB-Tap Scr.		705 4400		x 7/8" Lg.
			5/16 x .75" Lg.	63	725-1439		Safety Switch (Seat—Inner)
28	710-0134	١	Carriage Bolt 1/4-20 x .62"*	65	783-0345	N	Battery Tray
29	17770B	N	Running Board (R.H. & L.H.)	66	710-0351		Truss Mach. B-Tap Scr.
30	761-0168A		Blade Brake Ass'y.	67	749 0047		#10 x .5" Lg.
32	731-0909		Rubber Foot Pad—L.H.**	67	748-0347		Spring Spacer Truss Mach. Scr. 5/16-18 x .75"
l	731-0910		Rubber Foot Pad—R.H.**	68 69	710-0323		
24	723-0422	N	Abrasive Foot Pad** Lower Frame	70	710-0118 731-0405		Hex Bolt 5/16-18 x .75" Lg.* Snap Bushing
34	783-0310	IN	Lower Frame L-Wash. 3/8" I.D.*	71	731-0405	N	Battery Retainer Strap
36	736-0169		Insulator Boss Plate	72	712-3010	1.01	Hex Nut 5/16-18 Thd.
37	726-0278 736-0264		FI-Wash344" I.D. x .625" O.D.	73	712-3010		Hex Sems Nut 5/16-18 Thd.
38	710-0118		Hex Bolt 5/16-18 x .75" Lg.*	74	712-0203		Hex Sems Nut 1/4-20 Thd.
1 39	783-0042A	l N	Upper Frame—R.H.	, , ,	7 12 027 1		TIEX COMBINAL 1/4 20 THA.
33	100-0042A	19	Opper Frame—11.11.				

^{**}Optional Parts




PARTS LIST FOR MODELS 690 THRU 699 LAWN TRACTORS

REF. NO.	PART NO.	CODE	DESCRIPTION		REF. NO.	PART NO.	CODE	DESCRIPTION
1	783-0103		Connecting Rod		25	726-0272		Clamp
2	683-0029A		Pivot Link Ass'y.—L.H.		26	738-0526		Running Board Rod
3	683-0028A		Pivot Link Ass'y.—R.H.		27	710-3007		Hex Wash. Hd. Tap Scr.
4	17710		Deck Hanger Link Ass'		28	14802A		Link Deck Lift Ass'y.
5	14800A		Deck Hanger Link Ass'	'.	29	711-0723A		Adj. Ferrule 3/8-24 Thd.
6	14804A		Deck Hanger Link Ass'	'.	30	17712		Adj. Deck Lift Link
7	748-0331		Shld. Spacer .318" I.D.		31	712-3066		Hex Nut 1/2-20 Thd. (Gr. 5)
8	736-0264		Fl-Wash344" I.D. x .63	2" O.D.	32	711-0841		Lift Link Adjuster
9	736-0119		L-Wash. 5/16" I.D.*		33	17637A		Lift Shaft Ass'y.
10	712-3010		Hex Nut 5/16-18 Thd	Gr. 5	34	725-1657A	N	Safety Switch
12	714-0470		Cotter Pin 1/8" Dia.		35	714-0145		Inter. Cotter Pin 3/8" Dia.
13	736-0256		FI-Wash635" I.D. x 1.0	D" O.D.	36	732-0637		Extension Spring
14	683-0003		Height Adj. Stop Lever	Ass'y.	37	17636B		Stabilizer Bracket
			(Incl. Ref. 15)†	-	38	738-0670		Shaft 1/2" Dia. x 10.28" Lg.
15	08540		Knob†		39	732-0638		Extension Spring
16	710-0604		Hex Wash. TT-Tap Scr.		40	720-0233		Grip (Lift Handle)
			5/16-18 x .75" Lg.		41	97675A	N	Deck Lift Handle Ass'y.
17	748-0176		Flange Brg63" I.D.†		42	738-0669		Shaft 3/8" Dia. x 9.34" Lg.
18	710-1238		Hex Wash. Hd. Scr. 5/	6-18	43	747-0598		Disengagement Rod
			x .875" Lg.		44	97624	N	Stabilizer Shaft Ass'y.
19	710-0118		Hex Bolt 5/16-18 x .75"	Lg.	45	732-0556		Extension Spring 7.58" Lg.
20	17730		Index Brkt.		46	783-0043		Upper Frame—L.H.
21	782-0042A		Upper Frame—R.H.		47	741-0313		Flange Brg632" I.D.
23	736-0267		Fl-Wash385" I.D. x .81		49	716-0104		"E"-Ring
24	736-0160		Fl-Wash531" I.D. x .93	3" O.D.	50	736-0425		Bell-Wash325" I.D.

†Optional


Models 690 thru 699 (Single Cylinder—Low Noise)



PARTS LIST FOR MODELS 690 THRU 699 LAWN TRACTORS

REF. NO.	PART NO.	CODE	DESCRIPTION
1 2	710-0148 710-0599		Hex Slot Scr. #8-32 x .38" Lg. Hex Wash. TT-Tap Scr. 1/4-20 x .5" Lg.
3	710-0604		Hex Wash Hd. TT-Tap Scr. 5/16-18 x .62" Lg.
4	710-1314		Socket Hd. Bolt 5/16-18 x .62"
5	721-0208		Exhaust Gasket
6	726-0272		Clamp
6 7 8	736-0119		L-Wash. 5/16" I.D.*
8	751-0564		Muffler Deflector
9	751-0617		Muffler
	751-0618		Exhaust Pipe
	783-0320	N	Muffler Bracket
12	783-0385	N	Shield Bracket


Models 690 thru 699 (Single Cylinder)



PARTS LIST FOR ELECTRICAL SYSTEM

REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
1	629-0207		Harness Adapter (Mag.)	5	725-0925		Ammeter (Optional)
2	629-0302	N	Wire Harness w/Light Switch	6	725-0963		Bulb (Headlight)
			and Amp	7	725-1426		Solenoid
	629-0301	N	Wire Harness w/o Light Switch	8	725-1643		Safety Switch (Reverse)
Λ.			and Amp	9	725-1657A		Safety Switch
3	725-0267		Ignition Switch	10	725-1711	N	Wire Retainer Clip
4	725-0634		Light Switch (Optional)	11	726-3046	Ν	Ratchet


Models 690 thru 699 (Tecumseh)



PARTS LIST FOR MODELS 690 THRU 699 LAWN TRACTORS

	LAWN INACIONS								
REF. NO.	PART NO.	CODE	DESCRIPTION						
1	783-0385	N	Heat Shield Bracket						
	783-0378		Heat Shield						
3	783-0320	N	Muffler Bracket						
2 3 4 5 6 7 8 9	751-0535-1	2	Fuel Line						
5	751-0360A		Casing Clamp						
6	751-0617	1	Muffler						
7	751-0564		Muffler Deflector						
8	751-0620		Exhaust Pipe						
	751-0572		Hex Pipe Plug						
11	737-0286		Pipe 3/8 NPT x 3.8" Lg.						
	736-0119		L-Wash. 5/16" I.D.*						
	726-0272		Clamp						
	726-0205		Hose Clamp						
	721-0348		Exhaust Gasket						
	712-0271	N	Hex Sems Nut 1/4-20 Thd.						
	710-1314		Socket Hd. Bolt 5/16-18 x .62" Lg.						
19	710-1237		Hex Wash. Hd. Tap Scr.						
			#10-32 x .62" Lg.						
20	710-0599		Hex Wash. Hd. TT-Scr. 1/4-20 x .5" Lg.						
21	710-0604		Hex Wash. Hd. TT-Scr. 5/16-18						
			x .62" Lg.						
22	710-0148		Hex Bolt #8-32 x .38" Lg.						
23	710-1315		Hex Wash. Hd. TT-Scr. 3/8-16 x						
			1.25" Lg.						


Models 690 thru 699 (Tecumseh)



PARTS LIST FOR MODELS 690 THRU 699 LAWN TRACTORS

REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
1	629-0302	N	Wire Harness w/Light Switch and	5	725-0963		Bulb (Headlight)
			Amp	6	725-1426		Solenoid
	629-0301	N	Wire Harness w/o Ligh Switch	7	725-1643		Safety Switch (Reverse)
			and Amp	8	725-1657A		Safety Switch
2	725-0267		Ignition Switch	9	725-1711	Ν	Wire Retainer Clip
3	725-0634		Light Switch (Optional)	10	726-3046	Ν	Ratchet
4	725-0925		Ammeter (Optional)				·


Models 690 thru 699 (O.H.V.)



PARTS LIST FOR MODELS 690 THRU 699 LAWN TRACTORS

REF. NO.	PART NO.	CODE	DESCRIPTION						
1	710-1237		Hex Wash. Scr. #10-32 x .621						
	710-0148		Hex Tap Scr. #8-32 x .38" Lg.						
3	710-0599		Hex TT-Tap Scr. 1/4-20 x .5" Lg.						
4	710-0604		Hex TT-Tap Scr. 5/16-18 x .62"						
2 3 4 5	710-1314	N	Socket Head Scr. 5/16-18 x .62"						
	710-1315	N	Hex TT-Tap Scr. 3/8-16 x 1.25"						
6 7 8	712-0271		Hex Sems Scr. 1/4-20 Thd.						
8	721-0208		Gasket						
9	726-0205		Hose Clamp						
10	726-0272		Clamp						
11	731-1682A	N	Oil Drain Sleeve						
12	736-0119		Lock Washer 5/16" I.D.						
14	751-0535-1	2	Fuel Line 12" Lg.						
15	751B21314	6	Casing Clamp						
16	751-0564		Muffler Deflector						
17	751-0617	N	Muffler						
18	751-0619	N	Exhaust Pipe						
19	783-0320	N	Muffler Brkt.						
20	783-0385	Ν	Shield Brkt.						


Models 690 thru 699 (O.H.V.)



PARTS LIST FOR ELECTRICAL SYSTEM

REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
1	629-0132		Wire Harness (Monitor)	4	725-0925		Ammeter (Optional)
2	629-0306	N	Wire Harness w/Light Świtch,	5	725-0963		Bulb (Headlight)
			Amp and Monitor	6	725-1396		Ignition Switch
	629-0305	N	Wire Harness w/Light Switch	7	725-1426		Solenoid
			and Amp	8	725-1643		Safety Switch (Reverse)
r _h .	629-0304	Ν	Wire Harness w/o Light Switch	9	725-1657A		Safety Switch
			and Amp	10	725-1711	N	Wire Retainer Clip
3	725-0634		Light Switch (Optional)	11	726-3046	N	Ratchet


Models 690 thru 699 (Kohler)



PARTS LIST FOR MODELS 690 THRU 699 LAWN TRACTORS

REF. NO.	PART NO.	CODE	DESCRIPTION
1	710-0148		Hex Tap Scr. #8-32 x .38" Lg.
2	710-0599		Hex Wash. Hd. TT-Tap Scr.
			1/4-20 x .5" Lg.
3	710-0604		Hex Wash. Hd. TT-Tap Scr.
			5/16-18 x .62" Lg.
4	710-3206A		Hex Bolt M8-1.25 x 25 MM Lg.
5	712-3086		Hex Flange Nut M8-1.25 Thd.
6	721-0375		Exhaust Ğasket
4 5 6 7 8 9	726-0205		Hose Clamp
8	726-0272		Clamp
9	731-1682A	N	Oil Drain Sleeve
10	736-0607		Ext. L-Wash. 5/16" I.D.
12	751-0535-1	2	Fuel Line 12" Lg.
13	751-0564		Muffler Deflector
14	751-0617		Muffler
	751-0621		Exhaust Pipe
17	783-0320	N	Muffler Bracket
18	783-0385		Shield Bracket

Models 690 thru 699 (Kohler)




PARTS LIST FOR MODELS 690 THRU 699 LAWN TRACTORS


REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
1 2 3 4 5 6	629-0132 629-0209 629-0303 725-0267 725-0634 725-0925	N	Wire Harness (Monitor) Harness Adapter (Alt.) Wire Harness Ignition Switch Light Switch Ammeter	7 8 9 10 11 12	725-0963 725-1426 725-1643 725-1657A 725-1711 726-3046	N N	Bulb (Headlight) Solenoid Safety Switch (Reverse) Safety Switch Clip Ratchet

Models 690 thru 699 (Twin Cylinder)

PARTS LIST FOR MODELS 690 THRU 699 LAWN TRACTORS




REF. NO.	PART NO.	CODE	DESCRIPTION
1	710-0148		Hex Tap Scr. #8-32 x .38" Lg.
2	710-0599		Hex Wash. TT-Tap Scr. 1/4-20 x
_	7 10 0000		.5" Lg.
3	710-0604		Hex Wash. TT-Tap Scr. 5/16-18
•			x .62" Lg.
4	710-0779A		Truss Mach. Scr. #10 x .5" Lg.
5	710-1315		Hex Hd. Tap Scr. 3/8-16 x 1.25"
			Lg.
6	710-3015		Hex Bolt 1/4-20 x .75"Lg.
7	712-0271		Hex Sems Nut 1/4-20 Thd.
9	721-0346		Exhaust Gasket
10	726-0205		Hose Clamp
11	726-0272		Clamp
	736-0329		L-Wash. 1/4" I.D.*
13	736-3067		FI-Wash188" I.D. x .438" O.D.
	737-0143		Oil Drain Cap
	737-0164		Pipe Nipple 3/8 x 18 NPT.
17	751-0535-26	3	Fuel Line 26" Lg.
	751-0564		Deflector: Muffler
19	751-0616		Muffler
20	751-0623		Exhaust Pipe—L.H.
21	751-0624		Exhaust Pipe—R.H.
	783-0320	N	Muffler Bracket
23	783-0357	N	Heat Shield



PARTS LIST FOR MODELS 690 THRU 699 LAWN TRACTORS

REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
1	629-0132		Wire Harness (Monitor)	5	725-0634		Light Switch
2	629-0208		Harness Adapter	6	725-0925		Ammeter
3	629-0303	N	Wire Harness w/Light Switch,	7	725-0963		Bulb
			Amp and Monitor	8	725-1426		Solenoid
	629-0302	N	Wire Harness w/Light Switch and	9	725-1643		Safety Switch (Reverse)
			Amp	10	725-1657A		Safety Switch
4	629-0301	N	Wire Harness w/o Light Switch	11	725-1703		Harnéss Ass'y. (Oil—Optional)
1			and Amp	12	725-1711	N	Wire Retainer Clip
4	725-0267		Ignition Switch	13	726-3046	N	Ratchet




PARTS LIST FOR 38" MOWING DECK

	,		FARISTISTION				
REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
1	750-0776		Spacer .33" I.D. x .88"	23	742-0473A		High-Lift Blade
2	710-0672		Hex Bolt 5/16-24 x 1.25 " Lg.	25	748-0300		Blade Adapter
3	97503B	Ν	38" Deck Ass'y, w/Decl: Wheels	26	754-0433		V-Belt
	901-7503	Ν	38" Deck Ass'y. Comp. w/Deck	27	736-0270		Bell-Wash. 1/4" I.D.
			Wheels (For Service Only)	28	09322		Brake Disc
	17717B		38" Deck Ass'y, w/o Deck	33	710-0157		Hex Bolt 5/16-24 x .75" Lg.
			Wheels	35	712-0318		Hex Jam Nut 5/8-18 Thd.
	813-06102		38" Deck Ass'y. w/o Deck	37	736-0158		L-Wash. 5/8" I.D.*
			Wheels (For Service Only)	39	917-0906A	N	Blade Spindle Ass'y. Comp.
4	17665		Belt Guard Deck	42	756-0486		5" Dia. Pulley
6	710-0152		Hex Bolt 3/8-24 x 1.0" l.g.	52	703-1693		Hinge Mtg. Brkt.
8	710-0258		Hex Bolt 1/4-20 x .62"	53	732-0602		Torsion Spring
9	710-0888		Hex Bolt Special 5/16-24 x 1.0"	54	726-0106		Push Nut
10	711-0792		Hinge Pin	55	731-1032		Chute Ass'y. Comp. (Incl. Ref.
11	712-0123		Hex Nut 5/16-24 Thd.*			'	10, 52, 53, 54, 55)
13	712-0181		Hex Top L-Nut 3/8-16 1 hd.†	56	710-0157	i	Hex Bolt 5/16-24 x .75" Lg.
14	712-0287		Hex Nut 1/4-20 Thd.*	57	17493A		Deck Hanger Channel
17	734-0973		Deck Wheel—5"†	58	710-0599		Hex Wash. Hd. TT-Tap Scr.
18	736-0105		Bell-Wash40" I.D. x .88"				1/4-20 x .5" Lg.
			O.D.†	59	736-0242		Bell-Wash345" I.D. x .88"
19	736-0119		L-Wash. 5/16" I.D.*	60	17863		Skirt Ext.
20	736-0217		L-Wash. 3/8" I.D.—H.D	61	710-0167		Carr. Bolt 1/4-20 x .5" Lg.
22	738-0373		Shld. Bolt .498" Dia. x 1.53"†	62	712-0271		Hex Sems Nut 1/4-20 Thd.

^{*}For faster service obtain standard nuts, bolts and washe's locally. If these items cannot be obtained locally, order by part number and size as shown on parts list.

†Optional Deck Assembly with Wheels.

Deck "F" (38") Model 136A694F401 Only (Late Production)




PARTS LIST FOR 38" MOWING DECK

REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
2	710-1260		Hex Wash. Hd. TT-Tap Scr.	33	710-0157		Hex Bolt 5/16-24 x .75" Lg.
			5/16-18 x .75" Lg.	35	712-0417A		Hex Flange Nut 5/8-18 Thd.†
3	683-0129	N	38" Deck Ass'y.	37	736-0158		L-Wash. 5/8" I.D.*
	813-06459	Ν	38" Deck Ass'y. Comp.	39	618-0138	N	Blade Spindle Ass'y. Comp.
			(For Service Only)	1			(Incl. Ref. 28, 35, 42)
4	783-0343	Ν	Belt Guard Deck	42	756-0969		5" Dia. Pulley†
7	712-0291		Hex L-Nut 1/4-20 Thd.	52	703-1693		Hinge Mtg. Brkt.
8	710-0258		Hex Bolt 1/4-20 x .62"	53	732-0602		Torsion Spring
10	711-0792		Hinge Pin	54	726-0106		Push Nut
13	712-0181		Hex Top L-Nut 3/8-16 Thd.	55	731-1032		Chute Ass'y. Comp. (Incl. Ref.
14	712-3006		Hex Nut 1/4-20 Thd. (Gr. 5)				10, 52, 53, 54, 55)
17	734-0973		Deck Wheel—5"	56	710-0597		Hex Bolt 1/4-20 x 1" Lg.
18	736-0105		Bell-Wash40" I.D. x .88" O.D.	57	712-3087		Wing Nut 1/4-20 Thd.
22	738-0373		Shld. Bolt .498" Dia. x 1.53"	58	731-1643	N	Mulching Plug
23	742-0610	Ν	3 in 1 Blade	59	16606		Retainer Hook Brkt.
26	754-0329A		V-Belt	60	712-0271		Hex Sems Nut 1/4-20 Thd.
27	736-0270		Bell-Wash. 1/4" I.D.	61	710-0258		Hex Bolt 1/4-20 x .62" Lg.
28	783-0342		Brake Disc				

†Deck pulleys and blade nuts must be torqued to 100 ft. lbs. if removed or replaced.

^{*}For faster service obtain standard nuts, bolts and washers locally. If these items cannot be obtained locally, order by part number and size as shown on parts list.


Deck "H" (46")



Deck "H"

PARTS LIST FOR 46" MOWING DECK

k	PARTS LIST FOR 46" MOWING DECK								
≀EF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION		
1	618-0116		Blade Spindle Ass'y.	29	738-0373		Shld. Bolt .498" x 1.525"		
2	683-0067		46" Deck Ass'y.	30	741-0524		Ball Brg625" I.D. x 1.574"		
	913-06921	N	46" Deck Ass'y. Comp.				O.D. x .47"		
			(For Service)	31	742-0543		High Lift Blade 14.88" Lg.		
3	710-3151		Hex Bolt 5/8-18 x 4.25" Lg.	32	742-0542		High Lift Blade 16.28" Lg.		
4	710-0428		Hex Bolt 1/4-28 x 1.25" Lg.	33	748-0234		Shoulder Spacer		
5	710-0459		Hex Bolt 3/8-24 x 1.5" Lg.	34	750-0932A	N	Spacer .635" I.D. x .088" O.D.		
6	710-1039		Hex Bolt 3/8-24 x 1" Lg.	36	754-0440		V-Belt		
8	710-0599		Hex Wash. Hd. TT-Tap Scr.	37	754-0439		V-Belt		
_			1/4-20 x .5" Lg.	38	756-0638		Pulley Double Deck 5" O.D.		
9	710-0151		Hex Bolt 3/8-24 x 2" L.g.	39	756-0627		Flat Idler Pulley 3.5 O.D.		
10	710-1260		Hex Flange Bolt 5/16-24 x .75"	40	783-0046		Idler Deck Bracket		
			Lg.	41	783-0063A	N	Belt Cover L.H.		
11	710-1262		Hex Patch L-Bolt 7/16-20 x	42	17116		Deck Brake Brkt. Ass'y.		
40	744 0000		1" Lg.	43	17258A		Belt Cover Brkt. R.H.		
12	711-0993		Belt Guard Pin	44	710-0258		Hex Bolt 1/4-20 x .62" Lg.		
13	712-0138		Hex Nut 1/4-28 Thd.	45	711-0792		Hinge Pin		
14	712-0429		Hex Ins. L-Nut 5/16-18 Thd.	46	736-0270		Bell-Wash. 1/4" I.D.		
15	712-0241		Hex Nut 3/8-24 Thd.	47	732-0602		Torsion Spring		
16	712-3006		Hex Nut 1/4-20 Thd. (Gr. 5)	48	703-1693		Hinge Mtg. Brkt.		
17	712-0181		Hex Top Jam Nut 3/8-16 Thd.	49	726-0106		Push Nut		
18	712-0158		Hex Center L-Nut 5/16-18 Thd.	50	731-1032		Chute Ass'y. Comp. (Incl. Ref.		
19	716-3020		Int. Snap Ring	51	750-0960		45, 47, 48, 49, 50) Spacer .635" I.D. x 1" O.D.		
20	732-0594A		Ext. Spring .88" O.D. x 6.17"	52	736-0960		Spacer .635		
21	732-0723		Ext. Spring .788" O.D. x 15.5"	53	712-0337		Hex Nut 5/8-18 Thd.		
22	734-0973		Deck Wheel FI-Wash635" I.D. x 1" O.D. x	54	712-0337		Carriage Bolt 1/4-20 x .5" Lg.		
,23	736-0290		.06"	55	712-0271		Hex Sems Nut 1/4-20 Thd.		
24	726 0220		.06 L-Wash. 1/4" I.D.*	57	736-3088		FI-Wash635" I.D.		
24	736-0329		L-wash. 1/4 1.D." Bell-Wash. 3/8" x 1.125" x .062"	58	783-0141		Center Deck Skirt		
25	736-0331		Bell-Wash. 3/8" x .87" x .064"	59	783-0141 783-0142		R.H. Deck Skirt		
26	736-0105		Bell-Washer	59	100-0142		TI.T. DOCK ORIT		
27 28	736-0510		Shoulder Spacer .625" I.D. x		·				
20	738-0347		.169"						
			.103	<u>.</u>					



PARTS LIST FOR 42" MOWING DECK

REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
3	97600A	N	42" Deck Ass'y.	26	754-0371A		V-Belt
-	913-06119	Ν	42" Deck Ass'y. Comr.	27	736-0270		Bell-Wash. 1/4" I.D.
			(For Service Only)	28	09322		Brake Disc
4	17664		Belt Guard Deck	33	710-0157		Hex Bolt 5/16-24 x .75" Lg.
6	710-0152		Hex Bolt 3/8-24 x 1.0" Lg.	35	712-0318		Hex Jam Nut 5/8-18 Thd.
7	710-0599		Hex Wash. Hd. TT-Ta > Scr.	37	736-0158		L-Wash. 5/8" I.D.*
			1/4-20 x .5" Lg.	39	917-0906A	N	Blade Spindle Ass'y. Comp.
8	710-0258		Hex Bolt 1/4-20 x .62"	42	756-0556		5.5" Dia. Pulley
9	710-0888		Hex Bolt Special 5/16-24 x 1.0"	52	703-1693		Hinge Mtg. Brkt.
10	711-0792		Hinge Pin	53	732-0602		Torsion Spring
11	712-0123		Hex Nut 5/16-24 Thd.'	54	726-0106		Push Nut
13	712-0181		Hex Top L-Nut 3/8-16 Thd.	55	731-1032		Chute Ass'y. Comp. (Incl. Ref.
14	712-0287		Hex Nut 1/4-20 Thd.*		740 0457		10, 52, 53, 54, 55)
17	734-0973		Deck Wheel—5"	56	710-0157		Hex Bolt 5/16-24 x .75" Lg.
18	736-0105		Bell-Wash40" I.D. x 88"	57	17493A		Deck Hanger Channel
			O.D.	58	736-0242		Bell-Wash345" I.D. x .88"
19	736-0119		L-Wash. 5/16" I.D.*	59	710-0167		Carr. Bolt 1/4-20 x .5" Lg. Deck Skirt Ext.—Long
20	736-0217		L-Wash. 3/8" I.D.—H.I).	60 61	17861A 17961		Deck Skirt Ext.—Cong Deck Skirt Ext.—Short
22	738-0373		Shid. Bolt .498" Dia. x 1.53"	62	712-0271		Hex Sems Nut 1/4-20 Thd.
23 25	742-0499A 748-0300		High-Lift Blade Blade Adapter	02	112-0211		TIEX GEITIS NUL 1/4-20 THU.

^{*}For faster service obtain standard nuts, bolts and wasł ers locally. If these items cannot be obtained locally, order by part number and size as shown on parts list.